

Fabrikisto Stitching Frame Stands

Single-sided Stitching Frame Stand



Description

A versatile, well-made open-sided stand and support to hold your stitching project while you work hands-free! With a solid Maple base that's 25 mm (1") thick and 17 x 40 cm / 6.75 x 16" deep and wide, it's stable. Whether you prefer to set it on a table or on your lap, this 2 kg stand will hold your work securely. Either of the arms may be used separately, or combined to give full flexibility of placement.

For transport, the parts may be disassembled, or simply folded flat. Loosening the arm bolts makes it easier to fold the arms.

Assembly and Usage

Assembly is simple and easily repeatable. Please use the photo as a guide during assembly. **Please read these instructions completely before proceeding!**

1. Choose whether to use a single arm, and if so, which one. The shorter one is 15 cm (6") and the longer one is 25 cm (10")
2. If you choose to use both side arms, determine whether the shorter or longer will be attached to the base.
3. Remove the knob from the first arm's bolt, insert the bolt in the hole in one of the verticals, and reattach the knob. Note that the arm may be placed on either side of the vertical. Ensure that the knob isn't cross-threaded on the bolt. If it does not turn freely, back it off and try again. **Do not cross-thread!**
4. Repeat with the other arm if desired.
5. Remove the knob from a clamp, insert the bolt in the upper hole of an arm, then re-attach the knob, ensuring it is not cross-threaded.

6. Mount your frame, hoop, or stretcher bars as desired. Note that the clamp knob has a reverse thread – turn anti-clockwise (as seen from the top) to tighten.
7. Tighten all knobs to ensure your work stays in place.
8. For transport, loosen all knobs and lay the arms and clamps flat against the base. Re-tighten knobs so things stay in place.

Possible issues

- The arm clamps may not hold the arms firmly in position. Tighten them more!
- The clamp jaws may bind. Ensure that the jaws are parallel.
- The cross-dowels in the handles may come loose. Apply white glue and re-insert.
- The sliders may bind. Try loosening the clamps.

If you have any problems or suggestions, please contact Fabrikisto at contact@stitchingstands.com

Thank you!